



6. Structural Drawing and Replacement Parts



Replacement parts

No.	Part name	Piping thread type	Semi-standard specification	Part No.					
				AR20-D	AR30-D	AR40-D	AR40-06-D	AR50-D	AR60-D
(7)	Valve assembly	—	—	AR24P-060AS	AR34P-060AS	AR44P-060AS	AR49P-060AS	AR54P-060AS	AR64P-060AS
(8)	Diaphragm assembly	—	— : Relief	AR24P-150AS	AR34P-150AS	AR44P-150AS		AR54P-150AS	
			N : Non-relief	AR24P-150AS-N	AR34P-150AS-N	AR44P-150AS-N		AR54P-150AS-N	
(9)	Valve guide assembly	—	—	AR24P-050AS	AR34P-050AS	AR44P-050AS		AR54P-050AS	
(10)	Plug assembly	Rc/G	—	AR24P-370AS-01					
		NPT	—	AR24P-370AS-N01					
(11)	Blanking plate assembly	—	—	AR24P-250AS					
(12)	Plug assembly (Including part (10))	Rc	—	AR24P-320AS-01					
		NPT	—	AR24P-320AS-N01					
		G	—	AR24P-320AS-F01					
(13)	Check valve assembly	—	—	AR24KP-020AS					
(14)	Check valve plug assembly	—	—	AR20KP-090AS					

Note) The numbers in the table and structural drawings are consistent with the numbers in sections [10. How to Replace the Components] (P16-22) and [11. Disassembly Drawing] (P23-25).